



Shower Curtain Setup

Steps:

1. Attach black metal brackets to the rain gutter of the van.



2. Adjust the left rain gutter mount so that it lines up with the body seam between the 2 windows.



3. Insert the black aluminum pole into the upper sleeve of the shower curtain, starting at the Go-Shower logo end.

4. Insert aluminum pole into the rain gutter bracket hole, making sure that it goes all the way in.



5. Hold onto the right rain gutter bracket firmly (to hold it in place) and insert the other end of the aluminum pole into the hole.



6. Insert gold aluminum pole into lower section of the shower curtain.



7. Attach the side curtain magnets along both ends of the curtain to the side of the van.



8. In case of light winds, you may insert rocks or sand into the 2 lower pouches in order to keep the shower curtain more stable.

